

DIMENSION SEATPOST COLLAR INSTRUCTIONS

Thank you for purchasing a Dimension Seatpost Collar.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to:
www.dimensionbikeproducts.com/safety.

INTENDED USE

Dimensions seatpost collars secure your seatpost in your frame. They are intended for steel and alloy frames. They are not recommended for use on carbon fiber frames.

COMPATIBILITY

You must use the correct diameter seatpost collar. Use a caliper to measure the outside diameter of your frame's seat tube. If you are unsure, check with your local bicycle shop to verify the correct size.

⚠ WARNING: Incorrectly sized seatpost collars could cause the seatpost to slip while riding and lead to serious injury.

NOTE: If the Seatpost Collar is used with a carbon fiber frame or with a carbon fiber seatpost, or both, orient the slot in the seatpost collar 180° away from slot in frame.

NOTE: Make sure that your frame seat tube is free of any burrs or peeled paint. It may be necessary to gently sand the frame to achieve a smooth finish.

TOOLS

5mm Allen wrench

Grease

Torque wrench that measures in Nm

INSTALLATION

1. Lightly grease the top of the seat tube (figure 1).
2. Grease the threads of the seatpost bolt.
3. Slide the seatpost collar over the frame (figure 2). Insert the seatpost.
4. Tighten the seatpost collar to 3–5Nm.

NOTE: If the seatpost slips in the frame, increase torque incrementally until the saddle no longer twists. Do not attempt to fix a slipping or creaking seatpost by overtightening the seatpost collar. Consult a professional bike mechanic.



Figure 1



Figure 2

LIMITED 2-YEAR WARRANTY:

Dimension warrants this new Dimension product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of Dimension, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the Dimension product and is not transferable.

In no event shall Dimension be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

6400 WEST 105TH STREET
BLOOMINGTON, MN 55438
info@dimensionbikeproducts.com
1-855-883-6563

3123 08/13



DIMENSION
BICYCLE COMPONENTS