

DIMENSION STEERER ADAPTER 1" QUILL TO 1-1/8" THREADLESS INSTRUCTIONS

Thank you for purchasing a Dimension Steerer Adapter.

It is recommended that a professional bicycle mechanic install your Dimension™ steerer adapter, especially if you do not have access to a torque wrench.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

For additional product and safety information go to:
www.dimensionbikeproducts.com/safety

COMPATIBILITY & INTENDED USE



The Dimension Steerer Adapter is designed to fit on bicycles with 1" threaded forks and 1-1/8" threadless stems ONLY. It is intended for use on bicycles operated on paved surfaces, unpaved or gravel roads, trails with moderate grade, and irregular terrain where tires may lose contact with ground but drops are less than 6" (15cm).

TOOLS REQUIRED

- 6mm hex wrench
- Hex wrenches to fit your stem
- Torque wrench measuring in Nm
- Grease

PREPARATION

Before removing your old stem and handlebar, note the angle of the bars and the position of the brake levers and shifters.

If the old stem has a removable front cap, component removal is not necessary—just unbolt the front cap and remove the handlebar. If the old stem does not have a removable front cap, remove the components from one side of the handlebar, and loosen the handlebar binder bolt(s) on the stem. Loosen the quill bolt on your old stem several turns and then tap the bolt head to release the quill. Remove your old stem from the steerer tube and remove the handlebars from the stem. Carefully inspect your handlebars.

⚠ WARNING: A scratch or gouge in a handlebar can compromise its structural integrity and may cause serious injury.

Before installation, make sure the headset is properly installed and in good condition. Confirm that your fork features a 1" threaded steerer tube and that your stem features a 1-1/8" threadless clamp.

INSTALLATION

1. Grease the wedge mechanism, quill bolt, and inside of steerer tube.
2. Insert quill to at least the minimum insertion line.
⚠ WARNING: Use of steerer adapter if not inserted to the minimum insertion line could result in component failure, loss of control, and/or serious injury.
3. Tighten quill bolt to 10Nm.
4. Install your threadless stem per the stem manufacturer's specifications.

ONGOING MAINTENANCE

Periodically check to make sure the hardware on your stem and steerer adapter are tightened to the proper torque specification.

⚠ WARNING: Never operate your bicycle with the steerer adapter inserted to less than the minimum insertion line. Doing so could result in component failure, loss of control, and/or serious injury.

LIMITED 2-YEAR WARRANTY

Dimension warrants this new Dimension product against defects in materials and workmanship for two (2) years from the original date of retail purchase by the consumer. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of Dimension, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the Dimension product and is not transferable.

In no event shall Dimension be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from state to state.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the end user
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the Dimension product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Installation of components, parts, or accessories not originally intended for or compatible with Dimension products

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

